Camera Calibration

Course 3, Module 1, Lesson 2




Learning Objectives

- Learn how to find the camera matrix P through a process called camera calibration
- Learn how to extract the intrinsic and extrinsic parameters from the camera P matrix

Computing the Projection

Projection from World → Camera:

$$o_{image} = PO = K[R|t]O_{world}$$




Computing the Projection

World coordinates to Image coordinates:

$$o_{image} = \begin{bmatrix} x \\ y \\ z \end{bmatrix} = K[R|t] \begin{bmatrix} x \\ Y \\ Z \\ 1 \end{bmatrix}$$

• Image coordinates to Pixel coordinates:


$$\begin{bmatrix} x \\ y \\ z \end{bmatrix} \to \begin{bmatrix} u \\ v \\ 1 \end{bmatrix} = \frac{1}{z} \begin{bmatrix} x \\ y \\ z \end{bmatrix} \to \begin{bmatrix} su \\ sv \\ s \end{bmatrix}$$



Scale: s


lost when projecting from 3D to 2D

World coordinates and Camera coordinates known:



- Use scenes with known geometry to:
 - Correspond 2D image coordinates to 3D world coordinates
 - Find the Least Squares Solution (or non-linear solution) of the parameters of P

$$\begin{bmatrix} su \\ sv \\ s \end{bmatrix} = \begin{bmatrix} p_{11} & p_{12} & p_{13} & p_{14} \\ p_{21} & p_{22} & p_{23} & p_{24} \\ p_{31} & p_{32} & p_{33} & p_{34} \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$



Expanding the equation results in:

$$su = p_{11} X + p_{12} Y + p_{13} Z + p_{14}$$
(1)

$$sv = p_{21} X + p_{22} Y + p_{23} Z + p_{24}$$
(2)

$$s = p_{31} X + p_{32} Y + p_{33} Z + p_{34}$$
(3)

Move to LHS:

$$su - p_{11} X - p_{12} Y - p_{13} Z - p_{14} = 0$$

$$sv - p_{21} X - p_{22} Y - p_{23} Z - p_{24} = 0$$

$$s - p_{31} X - p_{32} Y - p_{33} Z - p_{34} = 0$$
(1)
(2)

• Replace Eq. (3) in Eq. (1) and Eq. (2) to get 2 equations per point:

$$p_{31}Xu + p_{32}Yu + p_{33}Zu + p_{34}u - p_{11}X - p_{12}Y - p_{13}Z - p_{14} = 0$$

$$p_{31}Xv + p_{32}Yv + p_{33}Zv + p_{34}v - p_{21}X - p_{22}Y - p_{23}Z - p_{24} = 0$$

- If we have N 3D points and their corresponding N 2D projections, set up homogeneous linear system
- Solved with Singular Value Decomposition (SVD)

Camera Calibration: Linear Methods

- Advantages of such a simple linear system are:
 - o Easy to formulate
 - Closed form solution
- Disadvantages of southe adistand plenting ear? system are:
- wiff o Does not directly provide camera parameters
 - Does not model radial distortion and other complex phenomena
 - Does not allow for constraints such as known focal length to be imposed

Factoring the P matrix

Projection Matrix: P = K[R|t]

3D Camera Center projects to zero:

Ra factorization

$$PC = 0$$

$$K[R|t]C = 0$$

$$K(RC + t) = 0$$

$$t = -RC$$

Substituting in to projection matrix:

$$P = K[R|-RC]$$

$$P = [KR|-KRC]$$

$$C = 0$$

Let M = KR

Factorizing the P matrix

$$P = [M|-MC]$$

$$M = \mathcal{R} Q$$

$$\frac{Q}{3 \times 3 \times 3 \times 3}$$

 \mathcal{R} is not our Rotation Matrix!

an orthogonal
basis

horrix

Factorizing the P matrix

$$M = \mathcal{R}Q = KR$$

• Intrinsic Calibration Matrix (upper triangular):

$$K = \mathcal{R}$$


Rotation Matrix (orthogonal):

$$R = Q$$

Translation Vector:

$$t = -K^{-1}P[:,4] = -K^{-1}MC$$

Camera Calibration



Summary

- The camera matrix P can be found through a process known as camera calibration
- The intrinsic and extrinsic camera parameters can be extracted from the P matrix using RQ factorization

Next: Stereo Vision

Calibration Tools – MOVE TO SUPPLEMENTAL MATERIALS

OpenCV:

o https://docs.opencv.org/master/d4/d94/tutorial camera calibratio n.html

Matlab:

 https://www.mathworks.com/help/vision/ug/single-cameracalibrator-app.html

ROS:

o http://wiki.ros.org/camera calibration